

# Welcome

Thank you for choosing the Mi Robot Vacuum-Mop Essential!  
Read this manual carefully before use, and retain it for future reference.

# Table of Contents

Safety information .....	03
Product Overview .....	05
Connect with Mi Home/Xiaomi Home App .....	08
How To Use .....	09
Care & Maintenance .....	14
FAQ .....	18
Specifications .....	19

# Safety information

---

## Usage Restrictions

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Make sure the vacuum-mop is turned off and the charging dock is unplugged before cleaning or performing maintenance.
- This vacuum-mop is only intended to clean floors in a home environment. Do not use it outdoors such as on an open balcony or on a surface that is not a floor, like a sofa, or in a commercial or industrial setting.
- Do not use the vacuum-mop in an area suspended above ground level, such as a loft, open balcony, or on top of furniture, unless a protective barrier is present.
- Do not use the vacuum-mop at an ambient temperature above 40°C or below 0°C or on a floor with liquids or sticky substances  
Charging Temperature: 0°C to 35°C.
- Please prepare the room before use, and give instructions for continuous care of the host.
- This appliance contains batteries that are only replaceable by skilled persons.
- Remove any cables from the floor before using the vacuum-mop to prevent it from dragging them while cleaning.
- Remove any fragile or loose items from the floor, such as vases or plastic bags, to prevent the vacuum-mop from being obstructed or bumping into them and causing damage.
- Do not place children, pets, or any item on top of the vacuum-mop while it is stationary or moving.
- Do not use the vacuum-mop to clean dark-colored carpet as dark carpets may not be able to be cleaned properly.
- Do not allow the vacuum-mop to pick up hard or sharp objects such as building materials, glass, or nails.
- Do not spray any liquid into the vacuum-mop. Make sure the dust compartment is thoroughly dry before reinstalling.
- Do not place the vacuum-mop upside down.

- Please keep the main brush cleaning tools out of reach of children.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not use the vacuum-mop to clean any burning substances.
- Under normal use of condition, this equipment should be kept a separation distance of at least 20cm between the antenna and the body of the user.
- Only use this product as directed in the user manual or quick start guide. Users are responsible for any loss or damage arising from improper use of this product.

## Battery and Charging

- Do not use any third-party battery, power adapter, or charging dock. Use only with < BLJ24W200120P-V> supply unit.
- Do not wipe any part of the vacuum-mop with a wet cloth or other liquid.
- Do not dismantle, repair, or modify the battery or charging dock on your own.
- Do not place the charging dock near a heat source, such as a radiator.
- Do not improperly dispose of old batteries. Before discarding the vacuum-mop, make sure the vacuum-mop is unplugged and the battery is removed and disposed of in an environmentally safe manner.
- Make sure the vacuum-mop is turned off when being transported and kept in its original packaging if possible.
- If the vacuum-mop will not be used for an extended period, fully charge it, then turn it off and store it in a cool, dry place.
- Recharge the vacuum-mop at least once a month to prevent battery damage.


Hereby, Xiaomi Communications Co., Ltd. declares that the radio equipment type Mi Robot Vacuum-Mop Essential MJSTG1 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <http://www.mi.com/global/service/support/declaration.html>



# Product Overview

---

## Vacuum-Mop



### Dock

Press to send vacuum-mop back to charging dock.  
Press again to pause.  
Press and hold for 5 seconds. After hearing a voice message, press and hold for 5 more seconds to restore factory settings.

### Power/Cleanup Button



Press and hold for 3 seconds to turn the vacuum-mop on or off when the vacuum-mop is not charging.  
Press to start or pause cleaning.

### + Simultaneously press and hold both buttons for 3 seconds to reset Wi-Fi.


### Status Indicator

Blinking orange: Error/Returning to dock to charge when running low battery.  
Slowly blinking orange: Charging (the battery level is low)  
Slowly blinking white: Charging (the battery level is more than 20%).  
Blinking white: Returning to dock to charge/Paused  
White: Cleaning/Fully charged.

## Side View




## Accessories



Charging Dock



Power Adapter



Mop Pad Holder




Mop Pad




Cleaning Brush

## Underside



## Charging Dock



# Connect with Mi Home/Xiaomi Home App

---



This product works with Mi Home/Xiaomi Home app. Control your device with Mi Home/Xiaomi Home app.



Scan the QR code to download and install the app. You will be directed to the connection setup page if the app is installed already. Or search "Mi Home/Xiaomi Home" in the app store to download and install it.

Open Mi Home/Xiaomi Home app, tap "+" on the upper right, and then follow prompts to add your device.

\* The app is referred to as Xiaomi Home app in Europe (except for Russia). The name of the app displayed on your device should be taken as the default.

Note: The version of the app might have been updated, please follow the instructions based on the current app version.

## Resetting Wi-Fi Connection

When switching to a new router or changing your Wi-Fi password, you will need to reset the vacuum-mop's Wi-Fi connection. To do so, turn on the vacuum-mop, then simultaneously press and hold the buttons "+" and "⏠" "⏏" for 3 seconds until you hear a voice saying "Resetting the Wi-Fi connection and entering network configuration mode". Once the Wi-Fi connection is reset, follow the in-app prompts to add the device.

Note: Only 2.4 GHz Wi-Fi networks are supported.

## Restoring Factory Settings


Press and hold the Dock button "⏠" for 5 seconds. Upon hearing a voice message, press and hold the Dock button again for 5 more seconds. Separate voice prompts will indicate when the reset begins and after it is completed. Restoring factory settings will clear all user data.



# How To Use


## 1. Before use

Remove the protective foam strips from both sides, and peel the protective film off the collision sensor.




## 2. Connect to the power supply


Open the bottom cover of the charging dock. Connect the power cord, and wrap any excess cord around the spool on the bottom of the dock, then remove the protective film from the IR sensor.



## 3. Place the charging dock on the level ground against a wall.




## 4. Turn on and charge the vacuum-mop. Press and hold the button "⊙" for 3 seconds to turn on the vacuum-mop. When the indicator lights up, manually place the vacuum-mop onto the charging dock to charge.




## Vacuuming Mode

Turn on the vacuum-mop. It is now ready to start cleaning.




2. Slide the assembled mop pad holder into the bottom of the vacuum-mop levely in the direction shown.




## Vacuuming & Mopping Mode

1. Open the lid and fill up the tank, then reattach the lid. Insert the 2-in-1 dust compartment with water tank into the vacuum-mop.



3. Turn on the vacuum-mop. It is now ready to start vacuuming and mopping.


Note: If the mop pad holder is not installed, only vacuuming mode will be used.




## Precautions:

- Do not place the charging dock in an area with direct sunlight.
- Make sure there are 0.5 meters or more of open space on either side of the charging dock and more than 1.5 meters in front.
- If the vacuum-mop is unable to turn on due to low battery, place it directly onto the charging dock to recharge.
- The vacuum-mop will automatically turn on when it is on the charging dock.
- The vacuum-mop cannot be turned off when it is on the charging dock.
- Remove the mop pad holder when the vacuum-mop is charging or not in use.
- Regularly clean the 2-in-1 dust compartment with water tank to prevent dirt buildup. This will help the vacuum-mop maintain optimal performance.
- Tidy up any loose cables on the floor before cleaning to prevent the vacuum-mop from dragging or getting caught on them.

## Turning On/Off

Press and hold the button "" for 3 seconds to turn on the vacuum-mop. The indicator will turn white and you will hear a voice message indicating that the vacuum-mop is in standby mode.

To turn off the vacuum-mop, press and hold the button "" while it is stationary. A voice message will indicate that the vacuum-mop is turning off.

Note: The vacuum-mop cannot be turned off while charging. If the vacuum-mop is unable to turn on due to low battery, manually place the vacuum-mop onto the charging dock to recharge.

## Starting/Pausing Cleanup

Turn on the vacuum-mop, then press the button "" to start cleanup.

To pause cleanup while the vacuum-mop is working, press the button ".

Note: The vacuum-mop cannot be used to clean up liquids. If the vacuum-mop is low on battery and cannot start cleaning, recharge it to a sufficient level before cleaning. If the vacuum-mop starts to run low on battery during a cleaning task, it will automatically return to the charging dock. Once its battery level is sufficient, the vacuum-mop will automatically resume cleaning where it left off. Before cleaning, tidy up any loose cables on the floor (including the charging dock power cord) to prevent the vacuum from dragging or getting caught on them, which could accidentally shut off electrical appliances or cause damage to objects or cables.

## Starting/Pausing Docking

Auto mode: The vacuum-mop will automatically return to the charging dock after it finishes cleaning.

Manual mode: Press the button "" to manually send the vacuum-mop to the charging dock.

When returning to the charging dock, the vacuum-mop's indicator blinks white, or blinks orange if the vacuum-mop runs low battery.

The indicator slowly blinks white while charging, and stays white when fully charged.

Note: If the vacuum-mop is unable to return to the charging dock due to an error, make sure there are no obstacles around the charging dock, then manually place the vacuum-mop onto the dock to recharge.

## Cleanup Modes

Upon cleaning up all, the vacuum-mop will methodically clean in the S-shape pattern and generate a real-time map in the Mi Home/Xiaomi Home app.

Note: Avoid moving the vacuum-mop while it is working, as this may cause the vacuum-mop to lose its position and remap its surroundings, which will reduce the vacuum-mop's cleaning efficiency.

### 1. Edge Cleanup

Enable the edge cleanup mode in the app. The vacuum-mop will clean along edges and walls for 30 minutes, then return to the charging dock.

### 2. Spot Cleanup

You can use the app to tell the vacuum-mop to clean a specific area on the map. Upon tapping Spot cleanup, the vacuum-mop will automatically navigate there and clean a 1×1 m area.

### 3. Scheduled Cleanup

You can schedule cleaning times in the app. The vacuum-mop will automatically start cleaning at the scheduled times, then return to the charging dock after the cleanup is completed.

## Adjusting Suction Power

Four suction modes are available in the app: Silent, Standard, Medium, and Turbo. The default mode is Standard.

## Adjusting Water Output

You can use the app to adjust the amount of water the vacuum-mop uses when mopping. Three water output modes are available: Low (1), Medium (2), and High (3). The default mode is Medium (2).

# Care & Maintenance

---

## Recommended Cleaning & Part Replacement Schedule

---


Component	Cleaning Frequency	Recommended Replacement Cycle
2-in-1 Dust Compartment with Water Tank	After each use	Replace if worn or damaged
Filter	Once a week	Every 6 months (or every 150 working hours)
Brush	Once a week	Every 6 to 12 months (or every 300 working hours)
Side Brush	Once a month	Every 3 to 6 months (or every 150 working hours)
Cleaning Brush	After each use	Replace if worn or damaged
Brush Cover	Once a month	Replace if the brush cover's silicone rubber strip becomes noticeably worn
Cliff Sensors	Once a month	No replacement necessary
Charging Contacts	Once a month	No replacement necessary
Caster Wheel	Once a month	Replace if worn or damaged
Mop Assembly	After each use	Replace if worn or damaged
Mop Pad	After each use	Every 3 to 6 months (or upon noticeable wear)

---


Note: Turn off the vacuum-mop and disconnect it from the power supply before performing cleaning or maintenance.  
Actual part replacement cycle may vary depending on usage conditions.

## Cleaning the 2-in-1 Dust Compartment with Water Tank


1. Open the cover of the vacuum-mop, then pinch the clips on both sides of the 2-in-1 dust compartment with water tank, as shown in the figure.




2. Take out the filter assembly, then remove the filter and sponge filter to clean them.



3. Empty the contents of the dust compartment. Clean the compartment using the cleaning brush, then align and reinstall the filter.




4. Reinstall the 2-in-1 dust compartment with water tank into the vacuum-mop until it clicks into place, then close the cover of the vacuum-mop.



## Cleaning the brush


1. Flip the vacuum-mop over and pinch the clips to remove the brush cover.
2. Remove the brush and brush bearings.
3. Reinstall the brush, then put the cover back on and press down until it locks into place.

Note: For best cleaning results, it is recommended to replace the brush every 6–12 months.



## Cleaning the Cliff Sensors


It is recommended to clean the cliff sensors every three months by using a soft cloth.






## Cleaning the Side Brush

Use a screwdriver to remove the screws holding the side brush in place. Clean the side brush, then reinstall it. For best cleaning results, it is recommended to replace the side brush every 3–6 months.




## Cleaning the Mop Pad

1. Pinch the side clips of the mop pad holder and pull to remove it, as shown in the figure.



2. Peel the mop pad away from the velcro on the mop pad holder, then slide it out of the groove as illustrated. Clean the mop pad with water, then reinstall it after it is thoroughly dry. It is recommended to replace the mop pad every 3 to 6 months, or when the pad becomes noticeably worn.



# FAQ

---

## Troubleshooting

Issue	Solution
Error 01: Left wheel error	There is too much load on the left wheel or it cannot turn. Check whether the left wheel is stuck.
Error 02: Right wheel error	There is too much load on the right wheel or it cannot turn. Check whether the right wheel is stuck.
Error 03: Cliff sensor error	The cliff sensor is not functioning properly. Check whether the sensor is dirty or obstructed.
Error 04: Low battery	Vacuum-mop runs at low battery level. Place the vacuum-mop onto the charging dock to recharge.
Error 05: Bumper error	The bumper is not functioning properly and may be jammed. Check to make sure the bumper is not stuck.
Error 06: Brush error	There is too much load on the brush or it cannot turn. Check whether the brush is stuck.
Error 07: Side brush error	There is too much load on the side brush or it cannot turn. Check whether the side brush is stuck.
Error 08: Fan error	The fan cannot rotate or is drawing excessive current. Try restarting the vacuum-mop. If the error persists, please contact after-sales service.
Error 09: Dust Compartment/ Water Tank	2-in-1 dust compartment with water tank is not detected. Check whether it is installed correctly.
Error 10: Charging error	Make sure the vacuum-mop is well connected to the charging dock.
Error 11: Insufficient water	The water tank has insufficient water. Refill the water tank.
Error 12: Vacuum-mop is off the ground	Move the vacuum-mop to a level surface and start again.

---

# Specifications

---

## Vacuum-Mop

---

Name	Mi Robot Vacuum-Mop Essential
Model	MJSTG1
Wireless Connectivity	Wi-Fi IEEE 802.11 b/g/n 2.4 GHz
Operation Frequency	2412-2472 MHz
Maximum Output Power	< 20 dBm
Rated Voltage	14.4 V $\Rightarrow$
Battery Runtime	Approx. 90 min (Standard Mode)
Rated Power	25 W
Battery Capacity	2500 mAh
Charging Time	4-5 h
Rated Input Voltage	20 V $\Rightarrow$
Rated Input Current	1.2 A
Service Life	1,000 hours of continuous operation

---

## Power Adapter

Information Published	Value and Precision	Unit
Manufacturer	Zhongshan Baolijin Electronic Co., Ltd.	-
Model Identifier	BLJ24W200120P-V	-
Input Voltage	100 - 240	V ~
Input AC Frequency	50/60	Hz
Output Voltage	20.0	V ==
Output Current	1.2	A
Output Power	24.0	W
Average Active Efficiency	86.2	%
Efficiency at Low Load (10 %)	80.1	%
No-load Power Consumption	0.10	W

## Charging Dock

Model	G1
Rated Input Voltage	20 V $\overline{=}$
Rated Input Current	1.2 A
Rated Output Voltage	20 V $\overline{=}$
Rated Output Current	1.2 A

## WEEE Information



All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.