

NVR Wireless Kit


Quick Operation Guide

V1.0 EN202111



Thank you for purchasing our products, if you have any questions or needs, please contact us.

Interface description



1. Install wireless NVR


Note:

- A. Disconnect the power from the NVR before installing a hard disk drive (HDD).
- B. The maximum of hard disk capacity supported is 8TB (Terabytes).


1-1. Install HDD for NVR

1-1-1. Install HDD for NVS001

Install the hard disk with a cross screwdriver.





- (1) Loosening the screws on the panel's rear and side.
- (2) Remove the cover from the NVR.



- (3) Remove the battery insulation paper.
- (4) Connect the data cable and power cable to HDD.
- (5) Fasten the screws on the bottom to fix the HDD.
- (6) Re-install the cover of the NVR and fasten screws.

1-1-2. Install HDD for NVS004


Install the hard disk with a cross screwdriver.



1-2. Connection NVR

- 1 Connect the mouse to the USB port of the NVR.
- 2 Connect to the monitor via an HDMI / VGA cable.
- 3 Connect to the internet (Router or Switch) via a net-cable (Local access please skip this step)
- 4 Connect to the DC 12V adapter and turn on the power.

Connection as below:



1-3. Connection the Cameras.

- 5 Power the camera through the DC adapter, and after 10 seconds, it will automatically connect to the NVR.

Note:

- A: The camera is connected to the NVR by default, and there is no need to configure WiFi.
- B: The distance between the wireless camera and the NVR is within 30 meters.


1-4. Complete the basic settings according to the NVR startup guide.

(NVR default password: 888888).

2. NVR Login

Follow the NVR startup wizard to complete the login settings.

(NVR default password: 888888)




3. Network Setting

When the network shows an abnormal state :

3-1. Check if your network cable is properly connected.

3-2. Double-click to open the network settings-select DHCP enable-OK.

3-3. If the DHCP function of the router is disabled, please enter the correct IP address manually.



4. SriHome APP Setup

Step 1. SriHome App Installation

Method 1: Scan the QR code to download "SriHome" App.

Method 2: Search "SriHome" on Google Play or iOS App Store.



Android



iOS

Step 2. Register & Login SriHome App

Step 3. Add the Device to App



3-1




3-2

You can scan the QR code or input the Device ID manually



The label is attached on the NVR


- Note:** A. The device ID is affixed to the label of the video recorder shell.
B. Enter Desktop/Main Menu--My Device--Version--Serial NO.



5. Reset


Go to Desktop>Control Panel>Restore>Please select the default setting item you want.



Note: If you forget who is the administrator. Please select "APP user", you can reset and become a new administrator.





6. Add the Camera

- Note:** 1. The camera and the wireless NVR have been paired at the factory.
2. Pair is only required for debugging and adding new cameras.



When the camera is powered on for 20 seconds, the camera emits "di", "di" and "di" prompts. Click the menu in the lower left corner of the display -> Click on  -> Click on  Icon distribution network -> Align the QR code with a distance of 20-60cm, no beeping" After the prompt tone of "di" and "di", it means that the network configuration is successful.

Note: 30 seconds after the camera is powered on, there is no prompt sound of "di", "di" or "di". Long press the Reset button for 5 seconds, let go after hearing the prompt and wait for the camera to restart.




Aim the camera lens at the QR code and keep a distance of 20-60cm. After the camera recognizes the QR code, the camera no longer emits the beeping "di", "di" and "di", indicating that the network configuration is successful. Wait a few seconds to see the video.

FAQ





1. Reset

Enter Desktop>Control Panel>Restore>Please select setting entries that you want to default.



2. If the user forgets his password, he can operate as follows

- ① Right click on the blank space, close the system>log out.
- ② Tick automatic login> click Restart in the lower right corner.
- ③ Tell the customer service the date in the lower right corner to reset the password
- ④ Right-click the mouse>Camera management>Enter the password notified by the customer service.



3. How to share more users to watch in APP

To protect the user's privacy, the first user is an administrator by default. Other users accessing the camera need administrator permission, or they cannot login even with ID and password. The way to get permission is as follows:

Access the “SriHome” App, tap Settings -> Visitor Management -> Add.

There are 2 types of permissions:

Operator: Live video view, set time, alarm, record and network.

Visitor: Viewing video only in real time

Note: You can find the user's App ID in **App Settings**

